


Standard Surface Sensor Part No. 1040

If the unit is to be bolted down as in a permanent installation, do not drill any hole outside of the innermost center recessed area. Damage to the internal wiring may result causing the unit to fail.



ALARM



WINLAND
ELECTRONICS, INC.
1950 Excel Drive
Mankato, MN., 56001
(507) 625-7231 Instate
(800) 635-4269 Outstate

NO ALARM